

ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler

MEURICE FLOOR LAMP

ASSEMBLY INSTRUCTIONS:

* Do not connect electricity until lamp is fully assembled. *

Unpack and place all parts on a soft surface.

1. Pulling down on cord firmly, thread column (E) into column (F).
2. Thread column (F) onto base (G)
3. Squeeze the harp (C) into the saddle (D).
4. Attach shade (B) onto harp (C).
5. Screw finial (A) onto harp (C) until tight.
6. Install light bulb Type A maximum 150 watts.
7. Remove protective plastic (H) from electrical plug (I).
8. Plug lamp into wall outlet.

Caution: To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.

Note: Turn the power off (unplug from the wall outlet) before replacing the bulb, making sure the bulb has had sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of bulb may result.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.

DO NOT ALTER THE PLUG.

